



# BELLARINE WORMS

## CFT WORM FARM SET-UP GUIDE

(Follow this Set-Up Guide by working up from bottom of page)



Step 6/ Put down lid, position according to time of year and you're ready to start worm farming

Step 5/ Install pre-soaked and gently wrung out worm farm blanket directly on top of paper layer

Step 4/ Install a damp newspaper layer x3 sheets thick directly on top of worms

**Note:** Brush and clean out box thoroughly and return to place of purchase if possible

Step 3/ Add your box of worms and spread evenly

Step 2/ Squeezing out excess moisture, add combined and pre-soaked shredded cardboard and coco coir peat bedding materials and spread evenly

Step 1/ Neatly install a damp newspaper layer x4 sheets thick and 2 layers wide directly onto pipes bringing up the sides of CFT approx 50mm

**Note:** Monitor liquid leachate run-off by checking the amount of liquid that accumulates at the bottom of your CFT worm farm (Refer to Beginners Guide)

**Note:** Combine and pre-soak Coco Coir Peat and shredded Cardboard for a min of 4 hours

### NOTE:

**1/ We recommend you first read the Bellarine Worms "A Beginners Guide to Worm Farming" as a general introduction.**

**2/ Once you have decided what size CFT worm farm suites your needs best, assemble and refer to the BW Set-Up Guide above working from the bottom up as illustrated.**